






**Building Bridge XG**




a



b



c



d



e



f



g




h



i



j




k



l


13mm






1

1





2





3





**4**


**A**




**10G**




**Internet**




**UniFi Gateway  
Console**



**Switch**






**B**

**1G**


**C**

**1G**


Internet




UniFi Gateway Console




Switch



Internet




UniFi Gateway Console




Switch



PoE++






5







6








10 Nm



7





If you need further assistance, visit our [Help Center](#) or contact [Ubiquiti Support](#).